
#### **Electric Circuits**

#### Eleventh Edition



**Chapter 3** 


Simple Resistive Circuits



#### **Learning Objectives**


- Resistors in Series
- Resistors in Parallel
- The Voltage/Current--Divider Circuit
- Voltage/Current Division
- Measuring Voltage and Current
- Measuring Resistance—The Wheatstone Bridge
- Delta-to-Wye (Pi-to-Tee) Equivalent Circuit

# Practical Perspective - Resistive Touch Screens






#### A Rear Window Defroster



A Rear Window Defroster



A resisEve circuit

#### 3.1 Resistors in Series




Figure 3.1: Resistors connected in series.

$$i_s = i_1 = -i_2 = i_3 = i_4 = -i_5 = -i_6 = i_7$$




Figure 3.2: Series resistors with a single unknown current  $i_s$ .

$$v_s = i_s(R_1 + R_2 + R_3 + R_4 + R_5 + R_6 + R_7)$$




Figure 3.3: A simplified version of the circuit shown in Fig. 3.2.

$$R_{eq} = R_1 + R_2 + R_3 + R_4 + R_5 + R_6 + R_7$$

$$v_s = i_s R_{eq}$$

$$\vdots$$

$$a R_1 R_2 R_3$$

$$\vdots$$

$$a R_1 R_2 R_3$$

$$\vdots$$

$$\vdots$$

$$a R_4$$

$$\vdots$$

$$h R_7 R_6 R_5$$

$$R_4$$

$$\vdots$$

$$h$$

$$\vdots$$

$$R_{eq}$$

$$\vdots$$

$$h$$

Figure 3.4: The black box equivalent of the circuit shown in Fig. 3.2.

In general, if k resistors are connected in series, the equivalent single resistor has a resistance equal to the sum of the k resistances:

$$R_{\text{eq}} = \sum_{i=1}^{k} R_i = R_1 + R_2 + \cdots + R_k$$



#### 3.2 Resistors in Parallel




Figure 3.5: Resistors in parallel.

$$i_s = i_1 + i_2 + i_3 + i_4$$

$$i_1R_1 = i_2R_2 = i_3R_3 = i_4R_4 = v_s$$



$$i_1 = \frac{v_s}{R_1}$$
  $i_2 = \frac{v_s}{R_2}$   $i_3 = \frac{v_s}{R_3}$   $i_4 = \frac{v_s}{R_4}$ 


$$i_s = v_s \left( \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3} + \frac{1}{R_4} \right)$$

$$\frac{i_s}{v_s} = \frac{1}{R_{eq}} = \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3} + \frac{1}{R_4}$$

$$\frac{1}{R_{\text{eq}}} = \sum_{i=1}^{k} \frac{1}{R_i} = \frac{1}{R_1} + \frac{1}{R_2} + \dots + \frac{1}{R_k}$$


$$G_{\text{eq}} = \sum_{i=1}^{k} G_i = G_1 + G_2 + \cdots + G_k$$

Figure 3.7: Replacing the four parallel resistors shown in Fig. 3.5



Conductance

## Typical Cases



• If k = 2, we have

$$\frac{1}{R_{\text{eq}}} = \frac{1}{R_1} + \frac{1}{R_2} = \frac{R_2 + R_1}{R_1 R_2} \qquad R_{\text{eq}} = \frac{R_1 R_2}{R_1 + R_2}$$

• If 
$$R_1 = R_2 = ... = R_k = R$$
, we have

$$1/R_{eq} = k/R \qquad \qquad R_{eq} = R/k$$

# 3.3 Voltage--Divider & Current-Divider Circuits

## The Voltage-Divider Circuit




Figure 3.14: (b) the voltage-divider circuit with current *i* indicated.



#### The Current-Divider Circuit




Figure 3.19: The current-divider circuit.

$$v = i_1 R_1 = i_2 R_2 = \frac{R_1 R_2}{R_1 + R_2} i_s$$

$$i_1 = \frac{R_2}{R_1 + R_2} i_s$$

$$i_2 = \frac{R_1}{R_1 + R_2} i_s$$



#### 3.4 Voltage/Current Division




Figure 3.20: Circuit used to illustrate voltage division.





Figure 3.21: Circuit used to illustrate current division.

#### 3.5 Measuring Voltage and Current

An **ammeter** is an instrument designed to measure current. A **voltmeter** is an instrument designed to measure voltage.



- An **ideal ammeter** has an equivalent resistance of  $0~\Omega$  and functions as a short circuit in series with the element whose current is being measured.
- An **ideal voltmeter** has an infinite equivalent resistance and thus functions as an open circuit in parallel with the element whose voltage is being measured.

# Digital and Analog Meters









#### d'Arsonval Meter Movement

d'Arsonval meter movement consists of a movable coil placed in the field of a permanent magnet. When current flows in the coil, it creates a torque on the coil, causing it to rotate and move a pointer across a calibrated scale. By design, the deflection of the pointer is directly proportional to the current in the movable coil. The coil is characterized by both a voltage rating and a current rating.




Figure 3.25: A schematic diagram of a d'Arsonval meter movement.

For example, one commercially available meter movement is rated at 50 mV and 1 mA. This means that when the coil is carrying 1 mA, the voltage drop across the coil is 50 mV and the pointer is deflected to its full-scale position.



# DC Ammeter/Voltage Circuit





Figure 3.26: An analog ammeter circuit.

Figure 3.27: An analog voltmeter circuit.





# Measuring Resistance: The Wheatstone Bridge




Figure 3.29: A balanced Wheatstone bridge ( $i_q = 0$ ).

$$R_{1}/R_{2} = i_{2}/i_{1}$$

$$R_{3}/R_{x} = i_{x}/i_{3} = i_{2}/i$$

In a commercial Wheatstone bridge,  $R_1$  and  $R_2$  consist of decimal values of resistances that can be switched into the bridge circuit.



# Delta-to-Wye (Pi-to-Tee) Equivalent Circuits




Figure 3.31: A resistive network generated by a Wheatstone bridge circuit.




Figure 3.32: A  $\Delta$  configuration viewed as a  $\pi$  configuration.




Figure 3.33: A Y structure viewed as a T structure.

## The Δ-to-Y Transformation




Figure 3.34: The  $\Delta$ -to-Y transformation.

$$R_{ab} = \frac{R_c(R_a + R_b)}{R_a + R_b + R_c} = R_1 + R_2$$

$$R_{bc} = \frac{R_a(R_b + R_c)}{R_a + R_b + R_c} = R_2 + R_3$$

$$R_{ca} = \frac{R_b(R_c + R_a)}{R_a + R_b + R_c} = R_1 + R_3$$

$$R_1 = (R_{ab} + R_{ca} - R_{bc}) / 2 = R_b R_c / (R_a + R_b + R_c)$$
  
 $R_2 = (R_{ab} + R_{bc} - R_{ca}) / 2 = R_c R_a / (R_a + R_b + R_c)$   
 $R_3 = (R_{bc} + R_{ca} - R_{ab}) / 2 = R_a R_b / (R_a + R_b + R_c)$ 

How about Y-to- $\Delta$ ?

#### The Y-to-∆Transformation


$$R_a = \frac{R_1 R_2 + R_2 R_3 + R_3 R_1}{R_1},$$

$$R_b = \frac{R_1 R_2 + R_2 R_3 + R_3 R_1}{R_2},$$

$$R_c = \frac{R_1 R_2 + R_2 R_3 + R_3 R_1}{R_3}.$$

# Practical Perspective - Resistive Touch Screens (0,0)

Figure 3.39: The resistive touch screen grid in the *x*-direction.






Figure 3.40: The pixel coordinates of a screen with  $p_x$  pixels in the x-direction and  $p_v$  pixels in the y-direction.




Figure 3.41: The resistive touch screen grid in the *y*-direction.